

Cloud Guide Quick Start Guide

Overview (on the next page you can see how to get here)

AurAir Cloud Dashboard

The AurAir Cloud Dashboard has the ability to display the measured CO2, Particulate matter and other Values.

Period

The measured AurAir sensor values can be displayed using a preset period. The preset periods are daily, Weekly, Monthly or a self-chosen period.

Devices

Using the Devices You Can choose a different AurAir to display. By clicking on the menu choice 'Manage Devices' You Can show the CO2, Particulate matter, temperature, humidity or VOC data per AurAir device.

CO2 Units

The left bar shows the CO2 units, the right bar the temperature/humidity.

User


By pressing the button you can see what your username is and change different settings.

Charts

The measured CO2 values are displayed as a solid green graph. Temperature is displayed as a purple line, humidity as a dotted line.

Time units

The bottom bar shows the time unit, which can vary from hours to days, weeks, months or years.



Your AurAir Cloud data

Cloud data

After adding the AurAir to your WiFi network and restarting the AurAir, unplugging the AurAir and plugging it back in, the AurAir has logged itself into the AurAir Cloud and received a Cloud username and password. On the right you can see how to see the AurAir Cloud username and password.

Institutions

Displays several important network settings, such as the administrator password, cloud username, and cloud password. If you forgot the administrator password, you can view it here. The cloud username and password are required to log in to the cloud. Go to <https://www.aurair.eu> and sign in to see your history!



Settings button

Press once: Switch the view to the settings page.
Press again om to switch back to the default display "CO2 value".

AurAir Cloud



AurAir Cloud URL

Cloud URL

The correct cloud URL (<https://www.aurair.net/>) is always on the homepage of the AurAir website, the AurAir website can be found at URL: <https://www.aurair.nl/>



AurAir Cloud



AurAir Cloud Dashboard Login or Sign In

Cloud username and password

After clicking on the Cloud URL, a web page will appear on which you can enter the AurAir Cloud data that you have previously read on the AurAir Base 2. Enter the username and password here.

Cloud Sign In

By signing up for the AurAir Cloud yourself, you get many additional options like setting up yourw **account** or devices. After that You can **log in with your** email address!

Password Forget?

Click here for a new password.

A screenshot of the AurAir Cloud Dashboard login page. The page has a dark blue header with the AurAir logo and the text 'AurAir Cloud Dashboard'. In the top right corner of the header, there are two links: 'Sign Up' and 'Sign In'. The main content area has a blue background with white clouds. A white sign-in form is centered on the page. The form has the AurAir logo at the top, followed by the text 'Welcome to the AurAir Cloud'. Below this, there is a bullet point that says 'You were signed out.' followed by two input fields: 'eMail (or AurAir ID)' and 'Password'. Below the password field is a Recaptcha checkbox with the text 'ik ben geen robot' and a Recaptcha logo. At the bottom of the form is a green 'Sign in!' button. Below the button are three links: 'General Terms and Conditions', 'Need to Sign Up?', and 'Forgot your password?'. A blue line with a dot at the end points from the 'Sign Up' link in the header to the 'Sign in!' button. Another blue line with a dot at the end points from the 'Forgot your password?' link to the 'Password Forget?' text box on the left.

AurAir Cloud



AurAir Devices Overview

AurAir Devices Overview

All your AurAir devices that you added in the dashboard are displayed here.

Device Location


AurAir devices are displayed using the entered location, if you have not entered a location, the AurAir ID is displayed here.

Devices List

All AurAir devices you add are listed in this list with their location name or if it has not been added with their AurAir ID.

Add device

To add an AurAir device to your dashboard, click the Add Device button.



Manage Devices

By pressing the Devices menu choice enters the AurAir Devices Overview

Change Device Settings

If you want to change something about your AurAir Device settings or remove your device from the dashboard, click [Edit] next to the respective device

Main Screen

Press the Cancel button to return to the main screen

AurAir Cloud



AurAir Devices Change Settings

Set up AurAir Devices

Here you can change and possibly delete your AurAir Devicesettings.

Device Location

AurAir devices are displayed using the entered location, if you have not entered a location, the AurAir ID is displayed here.

AurAir ID

Enter the AurAir ID Here.

Device Charts

Here you can set which charts to display with this device. The "watchdog" Option means that you can indicate whether you want an email if no values are received for more than a few hours.

Add device

To add an AurAir device to your dashboard, click the Add Device button.

AurAir Password

Here you enter the AurAir device password.

CO2 Borders

Here you can enter the CO2 limits:

- Medium Threshold, when the CO2 Value turns yellow
- High Threshold, when the CO2 value turns red

If you do not enter anything, the account will use default values.

Main Screen

Press the Cancel button to return to the main screen

Remove Device

Press the Delete Button to remove the device from the dashboard.

The screenshot shows the 'User AurAir Device' form on the AurAir Cloud Dashboard. The form is titled 'User AurAir Device' and features the AurAir logo. It contains the following fields and options:

- ID:** b2-7095938274
- Password:** pass5746
- Location:** OfficeBase2
- Name:** Nijmegen
- CO2-Medium-Threshold:** (empty)
- CO2-High-Threshold:** (empty)
- Watchdog:**
- Temperature Chart:**
- Humidity Chart:**
- Pressure Chart:**
- Wind Chart:**
- Buttons:** Update, Delete, Cancel

AurAir Cloud



Add AurAir Devices

Add AurAir Devices

All your AurAir devices that you added in the dashboard are displayed here.

Device Location

AurAir devices are displayed using the entered location, if you have not entered a location, the AurAir ID is displayed here.

AurAir ID

Enter the AurAir ID here.

Device Charts

Here you can set which charts to display with this device.
For a CO2 device, choose a CO2 graph and not a Particulate matter (PM) graph.
For a Particulate matter device, choose a PM graph and not a CO2 graph.

Add device

If you have entered all the data, press the 'Update' button to record the data. After that, press the Cancel button to go to the devices list.

AurAir Password

Here you enter the AurAir device password.

CO2 Borders


Here you can enter the CO2 limits:

- Medium Threshold, when the CO2 Value turns yellow
- High Threshold, when the CO2 value turns red

If you do not enter anything, the account will use default values.

Main Screen

Press the Cancel button to return to the main screen



AurAir Cloud




AurAir Cloud Download

Download Cloud Data

By clicking on the download symbol, the option to download the displayed data in Excel format appears.

Download Cloud Data

By clicking on the download button, the displayed data is downloaded in Excel format.



The screenshot shows the AurAir Cloud Dashboard with a 'Download CO2 data in Excel' dialog box open. The dialog box contains the following text:

Clicking "Download" exports the currently available CO2 data in Excel

Buttons: Close, Download

The dashboard background shows the following data points:

- Latest CO2: 476 ppm
- Latest Temperature: 22.5 °C
- Latest Pressure: 1020.7 hPa

The 'Download' button in the top right corner of the dashboard is highlighted.

Troubleshooting

Here are some things to consider when you're having trouble with the AurAir.

AurAir...	What is going on?	What am I supposed to do?
Does not have a password on the AurAir Base screen	The AurAir has not logged in to the AurAir Cloud, has the AurAir Base been reset after selecting the WiFi network and entering the password?	Unplug and re-insert AurAir Base.
I do have an AurAir Base username but no password.	The AurAir Base 2 cannot access the Internet, does the Wifi network use a so-called Captive Portal? That is a web page that requires you to log in to access the internet	Turn off the captive portal so that the AurAir Base can access the Internet.
I do have an AurAir Base username and also a password.	Due to an unknown error, you cannot log in to the AurAir cloud.	Go to the support section on the www.aurair.eu website and create a support ticket with the request for AurAir Cloud help.